





1



2






REF **BP B2 BASIC**
 ERP No./ # **BP3KA1-3N**



BP A3L Comfort (BP3GX1-3A)
 BP B3 Comfort (BP3KT1-4N)
 BP B3 Comfort PC (BP3KT1-4X)
 BP A6 Advanced Easy (BP3GU1-3E)

BP B3 AFIB Advanced (BP3KT1-3E)
 BP B6 Connect (BP3KV1-5X)
 BP B6 Advanced Connect (BP3KV1-5B)
 BP B6 Basic (BP3KV1-5N)



BP A2 Classic (BP3UG1-2E)
 BP A2 Standard (BP3UG1-2S)
 BP B2 Basic (BP3KA1-3N)
 BP B2 Easy (BP3KA1-1E)

BP B3 AFIB (BP3KT1-3N)
 BP B3 Basic (BP3KT1-3F)
 BP B3 BT (BP3KT1-4B)
 BP B3 Plus (BP3KT1-4F)



BP A150-30 AFIB (BP3MS1-4F)
 BP A150 AFIB (BP3MS1-2M)
 BP A200 AFIB (BP3MS1-4Y)
 BP A1 Basic (BP3GR1-3P)
 BP A1 Easy (BP3GR1-1P)
 BP A2 Basic (BP3GQ1-3P)
 BP A2 Easy (BP3GQ1-1P)
 BP A3 Basic (BP3GX1-4N)
 BP A3 Easy (BP3GX1-2N)
 BP A3L Basic (BP3GX1-3N)
 BP A3L PC (BP3GX1-3X)

BP A3 PC (BP3GX1-5X)
 BP A3 Plus (BP3GX1-5N)
 BP A5 PC (BP3GC1-5Y)
 BP A5 AFIB (BP3GC1-5F)
 BP A6 Basic (BP3GU1-7F)
 BP A6 BT (BP3GU1-7B)
 BP A6 Easy (BP3GU1-3F)
 BP A6 PC (BP3GU1-8Y)
 BP A6 Plus (BP3GU1-8F)
 BP A7 Touch (BP3GT1-6Y)
 BP A7 Touch BT (BP3GT1-6F)



BP B4 BT (BPHJB2-D)
 BP B2 Basic (BP3KA1-3N)
 BP B2 Easy (BP3KA1-1E)

BP B3 AFIB (BP3KT1-3N)
 BP B3 Basic (BP3KT1-3F)
 BP B3 BT (BP3KT1-4B)

BP B3 Plus (BP3KT1-4F)



BP B3 Comfort (BP3KT1-4N)

BP B3 Comfort PC (BP3KT1-4X)



BP B3 AFIB Advanced (BP3KT1-3E)
 BP B6 Connect (BP3KV1-5X)

BP B6 Advanced Connect (BP3KV1-5B)
 BP B6 Basic (BP3KV1-5N)